

IMPORTANT FITTING INFORMATION

LENCO

Mercedes nylon pulley

To fit the new pump, break the original nylon pulley to access the bolts of the front mounting bracket.

To break the pulley, strike with a hammer. Be careful not to damage/hit the rest of the pump.

